

FIELD ASSIGNMENT ENVIRONMENTAL MESSAGE (IAP) - ICS 204E

Incident Name: OTCW Oil to Lake	Date Prepared: 3/26/14	Operational Period:	
		Date	Time
Incident Location: Whiting Business Unit	Start:	3/26/14	12:00
	End:	3/27/14	00:00
ORGANIZATIONAL LEVEL:		FIELD ASSIGNMENT NO.	
<input checked="" type="checkbox"/> On-Scene Commander: Bob Hammer		<input type="checkbox"/> Task Force <input type="checkbox"/> Strike Team	
<input checked="" type="checkbox"/> Operations Section Chief: Ralph Alvarez			
<input checked="" type="checkbox"/> Branch: All: Shore, Water, 6 Sep			
<input type="checkbox"/> Division/Group:			
<input type="checkbox"/> Task Force/Strike Team: Waste Management Plan			

SPECIFIC ENVIRONMENTAL CONCERNS AND AVOIDANCE/MITIGATION MEASURES

Environmental Concerns:	Avoidance/Mitigation Measures:
Tracking of All Waste Materials	<ul style="list-style-type: none">- Utilize the Spill Material Tracking Event Log to record all material recovered from this event (liquid, solids, booms, socks pads,)- Return these logs to the Planning Section – Technical Lead at the end of every shift.
Solid waste management (i.e. booms, dry soil, etc)	<ul style="list-style-type: none">- Continue staging hazardous waste roll off boxes- Use hazardous waste roll-off boxes for material without free liquids- Heritage to manage labelling, manifesting and shipping. No oil containing material is to be shipped until approved by Planning Section – Technical and the EUL.- Use the appropriate box labelled for the material (i.e. 6 Separator box vs Shore box).- Heritage/Laborer supervisors to direct cleanup workers to segregate materials that contain oil versus those that do not obviously contain oil
Liquid oil soaked material (Limited scope)	<ul style="list-style-type: none">- Contact Heritage when drums are full for labelling/manifesting/transport. Heritage may allow drums to be dumped into roll-off boxes if free liquids are not observed in drums- Continue using vacuum trucks for managing liquids from 6 separator and recovered material from lake
Liquid Material	<ul style="list-style-type: none">- Discharge liquid material from vacuum trucks in:<ul style="list-style-type: none">- Lakefront Bar Screen (preferred option)- Alky Casper Sump (secondary option)
Beach Cleanup - accumulated oil	<ul style="list-style-type: none">- Keep 55 gallon drums staged in area remote from beach to prevent additional spills- Use hand tools to clean up accumulated oil from beach- Deposit accumulated oil in trash bags, deposit trash bags in 55-gallon haz waste drums
Decontamination of personnel	<ul style="list-style-type: none">- Use 55 gallon haz waste drums at decontamination stations to contain used PPE.- Allow Heritage to inspect 55 gallon drums containing waste PPE to evaluate for free liquid – if drums do not contain free liquid then contents of drum may be combined with material in haz waste roll off box

Equipment decontamination

- Equipment which can be moved via trailer may be moved to the cleaning pad for washing/decontamination

Prepared By: L. Wilson

ICS Position: Env Unit Lead

Phone: